

Instruktion für Schräghochparker SHP 4 / 5 / 6


 SHP 4 - 28 X
 SHP 5 - 32 X
 M8 x 18 SHP 6 - 36 X
 DIN 933

 SHP 4 - 2 X
 SHP 5 - 2 X
 M8 x 22 SHP 6 - 2 X
 DIN 933

 SHP 4 - 60 X
 SHP 5 - 68 X
 8,4 SHP 6 - 76 X
 DIN 125 A

 SHP 4 - 30 X
 SHP 5 - 34 X
 M8 SHP 6 - 38 X
 DIN 934

 SHP 4 - 2 X
 SHP 5 - 3 X
 SHP 6 - 3 X


 SHP 4 - 2 X
 SHP 5 - 2 X
 SHP 6 - 3 X

 Winkel 1250 mm - 2 x

 Winkel 2000 mm - 2 x

 SHP 4 - Winkel 1400 mm - 2 x + 1 x
 SHP 5 - Winkel 1750 mm - 2 x + 1 x
 SHP 6 - Winkel 2100 mm - 2 x + 1 x

 Strebe - 4 x





SHP 4



SHP 5



SHP 6

