

1870 MOTION (PDH)

this product is equipped with an associated two-lever synchro mechanism with multiple locking, anti-shock and sliding system



Seat height control: pull the paddle on right lever upward and release the lever piston in the required position.

Seat dept adjustment: pull the paddle on the left lever upward. Set up the required horizontal position and release the paddle. Seat is locked in in the nearest position.

Backrest angle adjustment: turn the left lever under the seat down to regulate the backrest tilted back or fixed in chosen position.

Tilting strenght adjustment: turn the right lever under the seat to adjust the strength of the tilting.

Back height adjustment : lift backrest in vertical direction and set up in the required position. Backrest will go down on the lowest position automatically by reaching the highest position.

Headrest adjustment: by pushing or pulling the headrest is possible to adjust angle and height of headrest in its entirety. (only for version with PDH).

Armrest adjustment: The armrest can be adjusted up and down pushing the button under the top cover. The armrest PU cover can be slid backward, according on the type of armrest.

Care and Maintenance

- To avoid possible personal injury, ensure all screws are fully tightened before using the chair. Periodically check the screws and ensure that they remain fully tightened.
- The chair is designed to a normal use in office environment, 8 hours a day. Warranty 24 months is valid only for this type of use. During the warranty period the manufacturer will replace any parts that present a defect.
- The maximum capacity of the chair is 130 kg.